



Certificate of Analysis

Sample: DA00605018-006

Harvest/Lot ID: 6

Seed to Sale #N/A

Batch Date :N/A

Batch#: 6

Sample Size Received: 10 gram

Retail Product Size: 10

Ordered : 06/05/20

Sampled : 06/05/20

Completed: 06/22/20 Expires: 06/22/21

Sampling Method: SOP Client Method

PASSED

Page 1 of 4

Jun 22, 2020 | Labyrinth Holdings LLC.

27349 Jefferson Ave. Suite #205
Temecula, CA, 92590, USA



PRODUCT IMAGE SAFETY RESULTS



Pesticides
PASSED



Heavy Metals
PASSED



Microbials
PASSED



Mycotoxins
PASSED



Residuals
Solvents
PASSED



Filtration
NOT TESTED



Water Activity
NOT TESTED



Moisture
NOT TESTED



Terpenes
NOT TESTED

MISC.

CANNABINOID RESULTS



Total THC
2.713%



Total CBD
86.430%



Total Cannabinoids
98.017%

CBC	CBGA	CBG	THCV	D8-THC	CBDV	CBN	CBDA	CBD	D9-THC	THCA
6.467%	ND	1.053%	0.065%	ND	1.289%	ND	ND	86.430%	2.713%	ND
64.670 mg/g	ND	10.530 mg/g	0.650 mg/g	ND	12.890 mg/g	ND	ND	864.300 mg/g	27.130 mg/g	ND
LOD 0.001 %	0.001 %	0.001 %	0.001 %	0.001 %	0.001 %	0.001 %	0.001 %	0.0001 %	0.0001 %	0.001 %

Cannabinoid Profile Test

Analyzed by : 450 Weight : 0.1150g Extraction date : 06/05/20 02:06:48 Extracted By : 965

Analysis Method -SOP.T.40.020, SOP.T.30.050 Reviewed On - 06/06/20 15:05:48
Analytical Batch -DA012964POT Instrument Used : DA-LC-003 Batch Date : 06/05/20 14:15:44

Reagent : 032320.27 Dilution : 400 Consums. ID : 280678841
060420.R16 914C4-914AK
060420.R15 929C6-929H

Full spectrum cannabinoid analysis utilizing High Performance Liquid Chromatography with UV detection (HPLC-UV). (Method: SOP.T.30.050 for sample prep and Shimadzu High Sensitivity Method SOP.T.40.020 for analysis. LOQ for all cannabinoids is 1 mg/L).

This report shall not be reproduced, unless in its entirety, without written approval from Kaycha Labs. This report is an Kaycha Labs certification. The results relate only to the material or product analyzed. Test results are confidential unless explicitly waived otherwise. Void after 1 year from test end date. Cannabinoid content of batch material may vary depending on sampling error. IC=In-control QC parameter, NC=Non-controlled QC parameter, ND=Not Detected, NA=Not Analyzed, ppm=Parts Per Million, ppb=Parts Per Billion. Limit of Detection (LoD) and Limit of Quantitation (LoQ) are terms used to describe the smallest concentration that can be reliably measured by an analytical procedure. RPD=Reproducibility of two measurements. Action Levels are State determined thresholds for human safety for consumption and/or inhalation. The result >99% are variable based on uncertainty of measurement (UM) for the analyte. The UM error is available from the lab upon request. The "Decision Rule" for the pass/fail does not include the UM. The limits are based on F.S. Rule 64-4.310.

Jorge Segredo
Lab Director

State License # n/a
ISO Accreditation # 97164



Signature

06/22/2020

Signed On



Certificate of Analysis

PASSED
Labyrinth Holdings LLC.

27349 Jefferson Ave. Suite #205

Temecula, CA, 92590, USA

Telephone: 9498426486

Email: bob@labxoil.com

Sample : DA00605018-006
Harvest/LOT ID: 6
Batch# : 6
Sampled : 06/05/20
Ordered : 06/05/20
Sample Size Received : 10 gram
Completed : 06/22/20 Expires: 06/22/21
Sample Method : SOP Client Method

Page 2 of 4



Pesticides

PASSED

Pesticides	LOD	Units	Action Level	Result	Pesticides	LOD	Units	Action Level	Result
ABAMECTIN B1A	0.01	ppm	0.3	ND	PRALLETHRIN	0.01	ppm	0.4	ND
ACEPHATE	0.01	ppm	3	ND	PROPICONAZOLE	0.01	ppm	1	ND
ACEQUINOCYL	0.01	ppm	2	ND	PROPOXUR	0.01	ppm	0.1	ND
ACETAMIPRID	0.01	ppm	3	ND	PYRETHRIN I	0.01	ppm	1	ND
ALDICARB	0.01	ppm	0.1	ND	PYRETHRIN II	0.01	ppm	1	ND
AZOXYSTROBIN	0.01	ppm	3	ND	PYRETHRINS	0.05	ppm	1	ND
BIFENAZATE	0.01	ppm	3	ND	PYRIDABEN	0.02	ppm	3	ND
BIFENTHRIN	0.01	ppm	0.5	ND	SPINETORAM	0.02	PPM	3	ND
BOSCALID	0.01	PPM	3	ND	SPINOSAD (SPINOSYN A)	0.01	ppm	3	ND
CARBARYL	0.05	ppm	0.5	ND	SPINOSAD (SPINOSYN D)	0.01	ppm	3	ND
CARBOFURAN	0.01	ppm	0.1	ND	SPIROMESIFEN	0.01	ppm	3	ND
CHLORANTRANILIPROLE	0.1	ppm	3	ND	SPIROTETRAMAT	0.01	ppm	3	ND
CHLORMEQUAT CHLORIDE	0.05	ppm	3	ND	SPIROXAMINE	0.01	ppm	0.1	ND
CHLORPYRIFOS	0.01	ppm	0.1	ND	TEBUCONAZOLE	0.01	ppm	1	ND
CLOFENTEZINE	0.02	ppm	0.5	ND	THIACLOPRID	0.01	ppm	0.1	ND
COUMAPHOS	0.01	ppm	0.1	ND	THIAMETHOXAM	0.05	ppm	1	ND
DAMINOZIDE	0.01	ppm	0.1	ND	TOTAL CONTAMINANT LOAD (PESTICIDES)	0	PPM	20	ND
DIAZANON	0.01	ppm	0.2	ND	TOTAL PERMETHRIN	0.01	ppm	1	ND
DICHLORVOS	0.01	ppm	0.1	ND	TOTAL SPINOSAD	0.01	ppm	3	ND
DIMETHOATE	0.01	ppm	0.1	ND	TRIFLOXYSTROBIN	0.01	ppm	3	ND
DIMETHOMORPH	0.02	ppm	3	ND	CHLORDANE *	0.01	PPM	0.1	ND
ETHOPROPHOS	0.01	ppm	0.1	ND	PENTACHLORONITROBENZENE (PCNB) *	0.01	PPM	0.2	ND
ETOFENPROX	0.01	ppm	0.1	ND	PARATHION-METHYL *	0.01	PPM	0.1	ND
ETOXAZOLE	0.01	ppm	1.5	ND	CAPTAN *	0.025	PPM	3	ND
FENHEXAMID	0.01	ppm	3	ND	CHLORFENAPYR *	0.01	PPM	0.1	ND
FENOXYCARB	0.01	ppm	0.1	ND	CYFLUTHRIN *	0.01	PPM	1	ND
FENPYROXIMATE	0.01	ppm	2	ND	CYPERMETHRIN *	0.01	PPM	1	ND
FIPRONIL	0.01	ppm	0.1	ND					
FLONICAMID	0.01	ppm	2	ND					
FLUDIOXONIL	0.01	ppm	3	ND					
HEXYTHIAZOX	0.01	ppm	2	ND					
IMAZALIL	0.01	ppm	0.1	ND					
IMIDACLOPRID	0.04	ppm	3	ND					
KRESOXIM-METHYL	0.01	ppm	1	ND					
MALATHION	0.02	ppm	2	ND					
METALAXYL	0.01	ppm	3	ND					
METHIOCARB	0.01	ppm	0.1	ND					
METHOMYL	0.01	ppm	0.1	ND					
METHYL PARATHION	0.005	ppm	0.1	ND					
MEVINPHOS	0.01	ppm	0.1	ND					
MYCLOBUTANIL	0.01	ppm	3	ND					
NALED	0.025	ppm	0.5	ND					
OXAMYL	0.05	ppm	0.5	ND					
PACLOBUTRAZOL	0.01	ppm	0.1	ND					
PHOSMET	0.01	ppm	0.2	ND					
PIPERONYL BUTOXIDE	0.1	ppm	3	ND					



Pesticides

PASSED

Analyzed by 585 , 795	Weight 1.0359g	Extraction date 06/10/20 09:06:12	Extracted By 1665 , 795
Analysis Method - SOP.T.30.065, SOP.T.40.065 , SOP.T.30.065, SOP.T40.070 Analytical Batch - DA013047PES , DA013071VOL Instrument Used : DA-LCMS-001_DER (PES) , DA-GCMS-001 Batch Date : 06/10/20 09:17:07			
Reagent	Dilution	Consums. ID	
050820.04 060920.017 041720.03 061020.020 061020.021	10	280678841 76262-590	
Pesticide screen is performed using LC-MS which can screen down to below single digit ppb concentrations for regulated Pesticides. Currently we analyze for 67 Pesticides. (Method: SOP.T.30.060 Sample Preparation for Pesticides Analysis via LCMSMS and SOP.T40.065 Procedure for Pesticide Quantification Using LCMS). * Volatile Pesticide screening is performed using GC-MS which can screen down to below single digit ppb concentrations for regulated Pesticides. Analytes marked with an asterisk were tested using GC-MS.			



Certificate of Analysis

PASSED
Labyrinth Holdings LLC.

27349 Jefferson Ave. Suite #205

Temecula, CA, 92590, USA

Telephone: 9498426486

Email: bob@labxoil.com

Sample : DA00605018-006
Harvest/LOT ID: 6
Batch# : 6
Sampled : 06/05/20
Ordered : 06/05/20
Sample Size Received : 10 gram
Completed : 06/22/20 Expires: 06/22/21
Sample Method : SOP Client Method

Page 3 of 4

	Residual Solvents	PASSED
--	--------------------------	---------------

	Residual Solvents	PASSED
---	--------------------------	---------------

Solvent	LOD	Units	Action Level (PPM)	Pass/Fail	Result
1,1-DICHLOROETHENE	0.8	ppm	8	PASS	ND
1,2-DICHLOROETHANE	0.2	ppm	5	PASS	ND
2-PROPANOL	50	ppm	500	PASS	ND
ACETONE	75	ppm	5000	PASS	ND
ACETONITRILE	6	ppm	410	PASS	ND
BENZENE	0.1	ppm	2	PASS	ND
BUTANES (N-BUTANE)	500	ppm	2000	PASS	ND
CHLOROFORM	0.2	ppm	60	PASS	ND
DICHLOROMETHANE	12.5	ppm	600	PASS	ND
ETHANOL	500	ppm	5000	PASS	ND
ETHYL ACETATE	40	ppm	5000	PASS	ND
ETHYL ETHER	50	ppm	5000	PASS	ND
ETHYLENE OXIDE	0.5	ppm	5	PASS	ND
HEPTANE	500	ppm	5000	PASS	ND
METHANOL	25	ppm	3000	PASS	ND
N-HEXANE	25	ppm	290	PASS	ND
PENTANES (N-PENTANE)	75	ppm	5000	PASS	ND
PROPANE	500	ppm	2100	PASS	ND
TOLUENE	15	ppm	890	PASS	ND
TOTAL XYLENES	15	ppm	150	PASS	ND
TRICHLOROETHYLENE	2.5	ppm	80	PASS	ND
XYLENES-M (1,3-DIMETHYLBENZENE)	13.5	ppm	2170	PASS	ND
XYLENES-M&P (1,3&1,4-DIMETHYLBENZENE)	27	ppm	2170	PASS	ND
XYLENES-O (1,2-DIMETHYLBENZENE)	13.5	ppm	2170	PASS	ND
XYLENES-P (1,4-DIMETHYLBENZENE)	13.5	ppm	2170	PASS	ND

Analyzed by 850	Weight 0.0273g	Extraction date 06/19/20 03:06:20	Extracted By 850
---------------------------	--------------------------	---	----------------------------

Analysis Method -SOP.T.40.032
Analytical Batch -DA013268SOL
Instrument Used : DA-GCMS-002
Batch Date : 06/18/20 16:28:12

Reviewed On - 06/21/20 08:52:11

Reagent	Dilution	Consums. ID
	1	H2017.077 00279984 161291-1

Residual solvents screening is performed using GC-MS which can detect below single digit ppm concentrations. Currently we analyze for 21 Residual solvents.(Method: SOP.T.30.032 Residual Solvents Analysis via GC-MS).



Certificate of Analysis

PASSED
Labyrinth Holdings LLC.

27349 Jefferson Ave. Suite #205

Temecula, CA, 92590, USA

Telephone: 9498426486

Email: bob@labxoil.com

Sample : DA00605018-006
Harvest/LOT ID: 6
Batch# : 6
Sampled : 06/05/20
Ordered : 06/05/20
Sample Size Received : 10 gram
Completed : 06/22/20 Expires: 06/22/21
Sample Method : SOP Client Method
Page 4 of 4

	Mycotoxins	PASSED
--	-------------------	---------------

Analyte	LOD	Units	Result	Action Level (PPM)
AFLATOXIN G2	0.002	ppm	ND	0.02
AFLATOXIN G1	0.002	ppm	ND	0.02
AFLATOXIN B2	0.002	ppm	ND	0.02
AFLATOXIN B1	0.002	ppm	ND	0.02
OCHRATOXIN A+	0.002	ppm	ND	0.02

Analysis Method -SOP.T.30.065, SOP.T.40.065
Analytical Batch -DA013048MYC | Reviewed On - 06/22/20 11:01:50
Instrument Used : DA-LCMS-001_DER (MYC)
Batch Date : 06/10/20 09:18:39

Analyzed by	Weight	Extraction date	Extracted By
585	NA	06/22/20 10:06:18	585

Aflatoxins B1, B2, G1, G2, and Ochratoxins A testing using LC-MS. (Method: SOP.T.30.065 for Sample Preparation and SOP.T40.065 Procedure for Mycotoxins Quantification Using LCMS. LOQ 1.0 ppb). Aflatoxin B1, B2, G1, and G2 must individually be <20ug/Kg. Ochratoxins must be <20µg/Kg.

Reagent	Consums. ID
052720.200	929C6-929H
052720.154	50AX26219
052720.165	19323
052720.82	25219065
052720.87	181019-274
052720.118	181207119C
052720.217	190827060
052720.218	
052720.275	
052720.282	
052720.250	
052720.48	
052720.63	
052720.269	
042920.253	

Microbiological testing for Fungal and Bacterial Identification via Polymerase Chain Reaction (PCR) method consisting of sample DNA amplified via tandem Polymerase Chain Reaction (PCR) as a crude lysate which avoids purification. (Method SOP.T.40.043) If a pathogenic Escherichia Coli, Salmonella, Aspergillus fumigatus, Aspergillus flavus, Aspergillus niger, or Aspergillus terreus is detected in 1g of a sample, the sample fails the microbiological-impurity testing.

	Microbials	PASSED
--	-------------------	---------------

Analyte	Result
ASPERGILLUS_FLAVUS	not present in 1 gram.
ASPERGILLUS_FUMIGATUS	not present in 1 gram.
ASPERGILLUS_NIGER	not present in 1 gram.
ASPERGILLUS_TERREUS	not present in 1 gram.
ESCHERICHIA_COLI_SHIGELLA_SPP	not present in 1 gram.
SALMONELLA_SPECIFIC_GENE	not present in 1 gram.

Analysis Method -SOP.T.40.043 / SOP.T.40.045
Analytical Batch -DA013188MIC | Reviewed On - 06/19/20 13:35:10
Instrument Used : PathogenDX PCR_Array Scanner DA-111,PathogenDX PCR_DA-171
Batch Date : 06/16/20 08:44:48

Analyzed by	Weight	Extraction date	Extracted By
513	1.0938g	06/16/20 03:06:19	513

Reagent	Dilution	Consums. ID
052620.14		SG298A
101519.12		918C4-918J

	Heavy Metals	PASSED
---	---------------------	---------------

Reagent	Reagent	Dilution	Consums. ID
061520.R01	061120.R01	100	89401-566
030920.02	061020.R13		
061520.R02	060120.R01		
061220.R02	061520.R05		
061520.R03			
061120.R02			

Metal	LOD	Unit	Result	Action Level (PPM)
ARSENIC	0.02	PPM	ND	1.5
CADMIUM	0.02	PPM	ND	0.5
LEAD	0.05	PPM	ND	0.5
MERCURY	0.02	PPM	ND	3

Analyzed by	Weight	Extraction date	Extracted By
53	0.2601g	06/16/20 04:06:32	457

Analysis Method -SOP.T.40.050, SOP.T.30.052
Analytical Batch -DA013210HEA | Reviewed On - 06/18/20 08:29:23
Instrument Used : DA-ICPMS-002
Batch Date : 06/16/20 15:54:17

Heavy Metals screening is performed using ICP-MS (Inductively Coupled Plasma - Mass Spectrometer) which can screen down to below single digit ppb concentrations for regulated heavy metals using Method SOP.T.30.052 Sample Preparation for Heavy Metals Analysis via ICP-MS and SOP.T.40.050 Heavy Metals Analysis via ICP-MS.